

INDUSTRIAL BRAIN	Standard Operating Procedure	Doc ID: SOP-01_Pump_Maintenance
	Effective: 2023-01-01	Rev: 1.0

SAFETY NOTICE: Ensure all Lockout/Tagout procedures are followed before commencing work.

Standard Operating Procedure: SOP-01

Title: Centrifugal Pump Maintenance Procedure **Last Updated:** 2023-01-15 **Author:** Alex Chen, Reliability Engineer

1. Purpose

To establish standard maintenance practices for all centrifugal pumps across the facility, specifically targeting the P-100 series (including Pump P-101).

2. Schedule

- Monthly:** Visual inspection for leaks.
- Quarterly:** Bearing lubrication with SynthoLube-X9.
- Bi-Annually:** Vibration analysis using handheld sensors.
- Annually:** Full teardown and seal replacement.

3. Procedure for Lubrication

- Ensure Lockout/Tagout (LOTO) per SOP-02.
- Clean the zerk fittings on the bearing housing.
- Apply exactly 15 grams of SynthoLube-X9.
- Rotate shaft manually to distribute grease.
- Record action in the maintenance log.

Warning: Failure to lubricate quarterly can result in premature bearing failure and catastrophic seal damage.

_____ Prepared By / Technician	_____ Approved By / Supervisor
-----------------------------------	-----------------------------------